


clear solutions Inc.


Spinner Display Assembly Instructions #8966

Phone 800-257-4550 E-mail info@cleardisplays.com


Tools Needed: flat screwdriver or thin coin (a dime works best)




1, Carefully unpack and identify all parts. 2 side panels, one top shelf, two lower shelves, and 4 binding post screws per shelf. Note that the top shelf is unique and the tall side of each shelf faces to the back of the unit.



2, On a clean flat surface, attach the center shelf to each side panel with the binding post screws.



3, For wall mount: If you are mounting on a wall, now is the time to attach the rack to the wall. Place mollie bolts (or wood screws with screw anchors) through the slots in the back plate.



4, Attach the top and bottom shelves. Once the shelves are attached, check for proper positioning and square and gently tighten all screws.